

- Model 205**
 with code 804 (Model year 2014)
 except code 800 (Model year 2020)
 except code 801 (YoM 20/1)
 except code 802 (YoM 21/1)
 except code 803 (YoM 22/1)
 except code 809 (Model year 2019)
- Model 205**
 with code 805 (Model year 2015)
 except code 800 (Model year 2020)
 except code 801 (YoM 20/1)
 except code 802 (YoM 21/1)
 except code 803 (YoM 22/1)
 except code 809 (Model year 2019)
- Model 205**
 with code 806 (Model year 2016)
 except code 800 (Model year 2020)
 except code 801 (YoM 20/1)
 except code 802 (YoM 21/1)
 except code 803 (YoM 22/1)
 except code 809 (Model year 2019)
- Model 205**
 with code 807 (Model year 2017)
 except code 800 (Model year 2020)
 except code 801 (YoM 20/1)
 except code 802 (YoM 21/1)
 except code 803 (YoM 22/1)
 except code 809 (Model year 2019)
- Model 205**
 with code 808 (Model year 2018)
 except code 800 (Model year 2020)
 except code 801 (YoM 20/1)
 except code 802 (YoM 21/1)
 except code 803 (YoM 22/1)
 except code 809 (Model year 2019)

- ☐ **Service A**
- ☐ **Service B**
- ☐ Plus package
- ☐ At every service (equipment specific)
- ☐ At every Service B
- ☐ Service 3 every service
- ☐ Service 3 at every service (not country-specific)
- ☐ Service 4 Every 2 years
- ☐ Service 8 every 20,000 km/3 years
- ☐ Service 8 every 20,000 km/3 years (not country-specific)
- ☐ Service 10 every 50,000 km/3 years
- ☐ Service 11 every 40,000 km/3 years (not country-specific)
- ☐ Service 11 every 150,000 km/5 years
- ☐ Service 12 every 20,000 km/3 years
- ☐ Service 12 every 40,000 km/3 years
- ☐ Service 13 every 200,000 km/10 years
- ☐ Service 13 every 200,000 km/10 years (not country-specific)
- ☐ Service 15 At every service B (not country-specific)
- ☐ Service 20 every 60,000 km/4 years



P00.20-2760-11

Customer.....

Order number.....

VIN/license plate number.....

Current mileage.....


















Completion time/date.....



Notes/explanations.....







The following activities are hereby confirmed:

- Completion of relevant service operations

Signature.....

A	B	Input condition not OK: 	
Completed <input checked="" type="checkbox"/> <input checked="" type="checkbox"/>   			
<input type="checkbox"/>	<input type="checkbox"/>	Service reception The pre-order for service on the vehicle is available in completed form.	 
<div style="border: 1px solid black; padding: 5px;">  To be performed by the Service Advisor (where market-specific conditions require). Fully process all acceptance items and the maintenance items listed in the service sheet, only then is the service scope completely performed. </div>			
<input type="checkbox"/>	<input type="checkbox"/>	Brake system Perform brake test and enter result in table.	 <div style="text-align: right; color: red;">AP42.00-P-4290BA</div>
<input type="checkbox"/>	<input type="checkbox"/>	Vehicle exterior Check condition of vehicle exterior.	 <div style="text-align: right; color: red;">AP60.00-P-0050H</div>
<input type="checkbox"/>	<input type="checkbox"/>	Check condition of windshield.	 <div style="text-align: right; color: red;">AP67.10-P-6750A</div>
<input type="checkbox"/>	<input type="checkbox"/>	Check condition of wiper blades.	 <div style="text-align: right; color: red;">AP82.30-P-8253G</div>
	<input type="checkbox"/>	Check exterior lighting for proper operation.	 <div style="text-align: right; color: red;">AP82.10-P-8252EW</div>
	<input type="checkbox"/>	Check function of headlamp range adjustment.	 <div style="text-align: right; color: red;">AP82.10-P-8250EW</div>
		Vehicles with dynamic LED headlamps or with the headlamp range adjuster on the exterior lights switch.	
	<input type="checkbox"/>	Check and correct headlamp adjustment.	 <div style="text-align: right; color: red;">AP82.10-P-8260E</div>
		<div style="border: 1px solid black; padding: 5px;">  The adjustment of headlamps on vehicles with level control system or dynamic LED headlamps is to be invoiced as an additional operation. </div>	
<input type="checkbox"/>	<input type="checkbox"/>	Check charging cable and vehicle socket for mechanical damage.	 <div style="text-align: right; color: red;">AP54.10-P-5458B</div>
		Model 205.047/147/247	
	<input type="checkbox"/>	Vehicle interior Check windshield wipers, windshield washer system for proper operation.	 <div style="text-align: right; color: red;">AP82.30-P-8252CAA</div>

<input type="checkbox"/>	<input type="checkbox"/>	Check starter.	<input type="radio"/>	
		Model 205.047/147/247			AP15.30-P-1550AA
<input type="checkbox"/>	<input type="checkbox"/>	Check starter.	<input type="radio"/>	
		Not country-specific.			
		Model 205.012/212			AP15.30-P-1550AA
	<input type="checkbox"/>	Replace activated charcoal particle filter.		AP83.00-P-8384CAA
<input type="checkbox"/>	<input type="checkbox"/>	Check warning and function indicator lamps in instrument cluster.	<input type="radio"/>	AP54.30-P-5451HA
<input type="checkbox"/>	<input type="checkbox"/>	Read out map data version from navigation system, check update.		AP82.85-P-8251D
		 Enter map data status:		
<input type="checkbox"/>	<input type="checkbox"/>	Read out and note maintenance data from instrument cluster, then reset service indicator.		AP00.20-P-0043E
Engine compartment					
<input type="checkbox"/>	<input type="checkbox"/>	Brake system: Check fluid level.	<input type="radio"/>	AP42.10-P-4210CAA
<input type="checkbox"/>	<input type="checkbox"/>	Check air flap in engine compartment.	<input type="radio"/>	
		Engine 177			AP20.00-P-2052B
<input type="checkbox"/>		Check low-temperature circuit coolant level.	<input type="radio"/>	
		Engine 177			AP20.30-P-2052F
		Engine 274			AP20.30-P-2052L
		Engine 276.8			AP20.30-P-2052H
<input type="checkbox"/>		Check low-temperature circuit coolant level.	<input type="radio"/>	
		Not country-specific.			
		Engine 651			AP20.30-P-2052N
<input type="checkbox"/>		Check coolant level in high-voltage battery circuit.	<input type="radio"/>	
		Model 205.047/147/247			AP08.50-P-2053C
<input type="checkbox"/>		Check all visible parts in engine compartment for damage and fluid loss.	<input type="radio"/>	AP00.20-P-0055C
<input type="checkbox"/>		Check poly-V-belt in visible area for signs of wear.	<input type="radio"/>	AP13.22-P-1352EW
		Engine 274 except model 205.047/147/247, engine 276			
<input type="checkbox"/>		Check poly-V-belt in visible area for signs of wear.	<input type="radio"/>	AP13.22-P-1352EW
		Not country-specific.			
		Engine 626, 651			AP13.22-P-1352EW
Underside of vehicle					
<input type="checkbox"/>		Check visible area of poly-V-belts for wear.	<input type="radio"/>	
		Engine 177			AP13.22-P-1352D
<input type="checkbox"/>		Check all visible parts of vehicle underside for damage and fluid loss.	<input type="radio"/>	AP00.20-P-0054E
		 The country-specific regulations for mobility and body shell complaints apply.			
<input type="checkbox"/>		Check condition of steering and tie rods.	<input type="radio"/>	AP46.00-P-4651A
<input type="checkbox"/>		Check condition of front axle and front axle joints.	<input type="radio"/>	AP33.10-P-3358A
<input type="checkbox"/>		Check condition of propeller shaft and flex disks.	<input type="radio"/>	AP41.10-P-4152EW
<input type="checkbox"/>		Check condition of rear axle and rear axle ball joints.	<input type="radio"/>	AP35.20-P-3552A

<input type="checkbox"/>		Check condition of suspension struts or shock absorbers and springs.	<input type="radio"/>	AP32.25-P-3255A
<input type="checkbox"/>	<input type="checkbox"/>	Assess condition and tire tread depth of tires and enter into table.	<input type="radio"/>	AP40.10-P-4052B
<input type="checkbox"/>	<input type="checkbox"/>	Assess condition of brake pads and enter into table.	<input type="radio"/>	AP42.10-P-4252CAA
<input type="checkbox"/>	<input type="checkbox"/>	Assess condition of brake disks and enter into table.	<input type="radio"/>	AP42.10-P-4256EW
<input type="checkbox"/>		Check tires for damage and crack formation, and enter result in table.	<input type="radio"/>	AP40.10-P-4051EW
Tires					
Plus package					
<input type="checkbox"/>	<input type="checkbox"/>	Correct tire pressure and enter set tire pressure in table.	<input type="radio"/>	AP40.15-P-4061A
Trunk					
Plus package					
<input type="checkbox"/>	<input type="checkbox"/>	Check/correct spare wheel tire pressure and enter set tire pressure in table.	<input type="radio"/>	AP40.15-P-4061A
		Vehicles with spare wheel.			
<input type="checkbox"/>	<input type="checkbox"/>	Check TIREFIT tire sealant.	<input type="radio"/>	AP40.10-P-4054R
		Vehicles with TIREFIT.			
		 Enter expiration date here:			
		 Replace TIREFIT, invoice as additional operation.			
<input type="checkbox"/>	<input type="checkbox"/>	Check first-aid kit (soft sided).	<input type="radio"/>	AP68.00-P-6850EW
		 Enter expiration date here:			
		 Replace first aid bag, invoice as an additional operation.			
<input type="checkbox"/>	<input type="checkbox"/>	Check trunk lighting for proper operation.	<input type="radio"/>	
Engine compartment					
Plus package					
<input type="checkbox"/>	<input type="checkbox"/>	Windshield washer system: Check/correct fluid level.		AP82.35-P-8210CAA
		 When using cleaning compounds for summer/winter, and depending on the ambient temperature, observe the mixing ratio.			
		If the fill level is too low,			
		↓			
		add cleaning compound.			
		 Subject to a separate invoice.			
Vehicle interior					
Plus package					
<input type="checkbox"/>	<input type="checkbox"/>	Check lamps in instrument cluster and interior lighting for proper operation.	<input type="radio"/>	AP54.30-P-5453CAA
Vehicle interior					
At every service (equipment specific)					
<input type="checkbox"/>	<input type="checkbox"/>	Check ex-factory driving aids.	<input type="radio"/>	AP86.20-P-8649U
		With code 45P (Modification to meet the needs of disabled users - Sales control code)			
<input type="checkbox"/>	<input type="checkbox"/>	Fill up or replace vial of perfume atomizer.		

<input type="checkbox"/>	<input type="checkbox"/>	<p>Replace battery for KEYLESS-GO key.</p> <p>-----</p> <p>After consultation with customer. Model 205 (except model 205.4) with code P21 (Air quality package)</p>	AP83.10-P-0100A
<input type="checkbox"/>	<input type="checkbox"/>	<p>External refueling At every service (equipment specific) AdBlue® container: Top up fluid level.</p> <p>-----</p> <p>After consultation with customer. With code 889 (KEYLESS-GO) or with code 893 (KEYLESS-Start)</p>	AP14.40-P-1410BT
	<input type="checkbox"/>	<p>Engine compartment At every Service B Replace dust filter.</p> <p>-----</p>	AP83.00-P-8381B
	<input type="checkbox"/>	<p>Underside of vehicle At every Service B Check front axle.</p> <p>-----</p> <p>Except code 489 (AIRMATIC) and except code M005 (Vehicles with 4MATIC/all-wheel drive)</p>	AP33.10-P-3311A
<input type="checkbox"/>	<input type="checkbox"/>	<p>Engine compartment Service 3 every service Engine: Change oil and oil filter.</p> <p>-----</p> <p>Engine 177 Engine 274.910, engine 274.920 except code M005 (Vehicles with 4MATIC/all-wheel drive) Engine 274.920 with code M005 (Vehicles with 4MATIC/all-wheel drive) Engine 276</p>	<p>AP18.00-P-0101D AP18.00-P-0101CWI AP18.00-P-0101CWE AP18.00-P-0101CWZ</p>
<input type="checkbox"/>	<input type="checkbox"/>	<p>Engine compartment Service 3 at every service (not country-specific) Engine: Change oil and oil filter.</p> <p>-----</p> <p>Engine 626 Engine 651</p>	<p>AP18.00-P-0101B AP18.00-P-0101CWB</p>
<input type="checkbox"/>	<input type="checkbox"/>	<p>Engine compartment Service 4 Every 2 years Brake system: Replace brake fluid.</p> <p>-----</p>	AP42.00-P-4280EW
<input type="checkbox"/>	<input type="checkbox"/>	<p>Underside of vehicle Service 8 every 20,000 km/3 years Rear axle: Change oil.</p> <p>-----</p> <p>With code 467 (Electronic locking differential) or with code 471 (Mechanical locking differential)</p>	AP35.00-P-3501CMG
<input type="checkbox"/>	<input type="checkbox"/>	<p>Engine compartment Service 8 every 20,000 km/3 years Replace air filter element.</p> <p>-----</p> <p>Engine 177 Engine 274 Engine 276.8</p>	<p>AP09.10-P-0980I AP09.10-P-0980CWG AP09.10-P-0980E</p>
<input type="checkbox"/>	<input type="checkbox"/>	<p>Engine compartment Service 8 every 20,000 km/3 years (not country-specific) Replace air filter element.</p> <p>-----</p> <p>Engine 626 Engine 651</p>	<p>AP09.10-P-0980F AP09.10-P-0980EWD</p>

<input type="checkbox"/>	<input type="checkbox"/>	Vehicle interior Service 10 every 50,000 km/3 years Panoramic sliding sunroof: Clean and lubricate guide mechanism.	<p>-----</p> <p>With code 413 (Panoramic sliding sunroof/glass roof)</p>	AP77.20-P-7732CW
<input type="checkbox"/>	<input type="checkbox"/>	Underside of vehicle Service 11 every 40,000 km/3 years (not country-specific) Replace fuel filter.	<p>-----</p> <p>Engine 626</p>	AP47.20-P-0780A
<input type="checkbox"/>	<input type="checkbox"/>	Engine compartment Service 11 every 40,000 km/3 years (not country-specific) Replace fuel filter.	<p>-----</p> <p>Engine 651</p>	AP47.20-P-0780EWD
<input type="checkbox"/>	<input type="checkbox"/>	Vehicle interior Service 11 every 150,000 km/5 years Replace fuel filter.	<p>-----</p> <p>Engine 177, 274.9, 276.8</p>	AP47.20-P-0780M
<input type="checkbox"/>	<input type="checkbox"/>	Engine compartment Service 12 every 20,000 km/3 years Replace spark plugs.	<p>-----</p> <p>Engine 177</p>	AP15.10-P-1580C
<input type="checkbox"/>	<input type="checkbox"/>	Engine compartment Service 12 every 40,000 km/3 years Replace spark plugs.	<p>-----</p> <p>Engine 274 Engine 276.8</p>	AP15.10-P-1580CWF AP15.10-P-1580D
<input type="checkbox"/>	<input type="checkbox"/>	Underside of vehicle Service 13 every 200,000 km/10 years Replace coolant in main circuit.	<p>-----</p> <p>Engine 177, 274, 276.8</p>	AP20.00-P-2082K
<input type="checkbox"/>	<input type="checkbox"/>	Replace low-temperature circuit coolant.	<p>-----</p> <p>Engine 177 Engine 274 Engine 276.8</p>	AP20.00-P-2083C AP20.00-P-2083E AP20.00-P-2083I
<input type="checkbox"/>	<input type="checkbox"/>	Underside of vehicle Service 13 every 200,000 km/10 years (not country-specific) Replace coolant in main circuit.	<p>-----</p> <p>Engine 626, 651</p>	AP20.00-P-2082K
<input type="checkbox"/>	<input type="checkbox"/>	Replace low-temperature circuit coolant.	<p>-----</p> <p>Engine 651</p>	AP20.00-P-2083G
	<input type="checkbox"/>	Vehicle exterior Service 15 At every service B (not country-specific) Trailer hitch: Check condition and operation.	<p>-----</p> <p>With code 550 (Trailer hitch)</p>	AP31.11-P-3152CW
<input type="checkbox"/>	<input type="checkbox"/>	Underside of vehicle Service 20 every 60,000 km/4 years Automatic transmission: Change oil and oil filter.	<p>-----</p> <p>Transmission 722.9 Transmission 724.2 Transmission 725.0 except code M005 (Vehicles with 4MATIC/all-wheel drive)</p>	AP27.00-P-2702W AP27.00-P-2702A AP27.00-P-2702B
<input type="checkbox"/>	<input type="checkbox"/>	Automatic transmission and transfer case: Change oil and automatic transmission oil filter.	<p>-----</p> <p>Transmission 725.0 with code M005 (Vehicles with 4MATIC/all-wheel drive)</p>	

Brake values

	Left	Right
Front		
Rear		
Parking brake		

Condition of tires/tire tread depth (Mark applicable field with X or optionally, enter tire tread depth)

	Right front	Left front	Right rear	Left rear
Condition and tire tread depth OK.				
Wear limit reached / exceeded				
Unusual wear pattern				
Max. tire age / mileage reached / exceeded (special protection only)				

Condition of brake linings (Mark applicable field with X)

	Right front	Left front	Right rear	Left rear
Condition in visible area OK.				
Wear limit reached / exceeded				
Soiled (oil, grease, etc.)/ damaged.				

Condition of brake disks (Mark applicable field with X)

	Right front	Left front	Right rear	Left rear
Condition in visible area OK.				
Wear / damaged (e.g.: score marks, cracks, corrosion, chippings, deeply contoured ridging with steel brake disks)				
Soiled (oil, grease, etc.)				

Set tire pressure in bar or psi

	Front axle	Rear axle	Spare wheel
bar/psi			